

Five common poultry watering myths

Compared to half a century ago, the poultry industry has become highly technical. Misconceptions about poultry watering practices can, however, make that technology irrelevant and seriously impact results. To make the best use of your watering system, you need to know what the myths are and what the facts are.

By the Technical team of Ziggity Systems Inc, Middlebury, Indiana, US. (www.ziggity.com)

The poultry industry has come a very long way during the last 50 years, moving from backyard flocks to highly technical operations. Producers worldwide are moving away from open bell- and trough-type watering systems toward enclosed nipple-type systems.

Modern nipple-type systems require less labor to maintain, but they also demand much closer attention from the poultry farmer. Ziggity's sales representatives spend substantial time in the field working with poultry farmers to help maximise their production. They report that many times the roadblocks to better profits are misconceptions about watering practices.

Myth 1: Increasing the water pressure will force birds to drink more.

Broilers drink approximately 0.7 - 0.8 kg of water for every 0.45 kg of feed they consume. However, birds can only drink



so much. You cannot force them to drink more in an effort to make them eat more. In reality, increasing the pressure delivers more water than the birds can hold in their beaks. The excess water spills onto the litter, elevating ammonia levels that harm the birds and contribute to poor flock performance.

Virtually all manufacturers of nipple-type drinkers without catch cups recommend minimum pressure settings for day-old chicks. Most manufacturers recommend settings below 10 cm to start. Ziggity systems recommend only 2.5 - 5 cm of column height pressure to ensure dry litter from the very start. After the first week, manufacturers differ on pressure settings but generally do not go beyond 51 cm of column height.

One needs to examine the litter conditions to determine the correct pressure setting. If the litter is wet, reduce the pressure until it starts to dry. Only then, increase the pressure. Producers should strive for dry, friable litter.

Myth 2: A water metre where the water line enters the poultry house will tell you how much water the birds consume.

This one confuses even some of the experts. The water metre measures the

amount of water that goes into the house. It cannot tell you how much water the birds drink, how much is spilled onto the litter or how much simply evaporates.

Use the water metre as an early warning device. If water usage goes down unexpectedly, consider the possibility that a disease is causing the birds to drink less or that a portion of the drinker line is blocked, preventing water from getting to all of the birds. If water usage goes up, check for leaks in the system or a break in the line.

Myth 3: Using chemical additives will improve your return on investment.

This is a tricky one. Research has shown that lowering the pH and adding chlorine to the birds' water destroys harmful bacteria both in the watering lines and in the birds' crops. Some poultry farmers also have had success at decreasing ammonia levels by putting acidifiers on the litter. The acids attack the bacteria that facilitate the breakdown of uric acid. While this might promote bird growth, it may hurt your return on investment in the long run.

Many of these chemicals are acids and are inherently corrosive. Excessively

high levels of these chemicals in the watering lines can potentially damage drinker components, such as stainless steel balls, seats and triggers and metering pins in nipple-type drinkers. Acid in the litter can cause damage to other metal components in the poultry house, such as brooder stove canopies and watering system support pipes. So, an attempt to improve production can result in extensive equipment damage requiring early replacement. The key is to either use levels or concentrations of these chemicals that do not harm the equipment, or avoid using corrosive chemicals altogether.

It is recommended that producers use chemical additives only after very careful consideration. Know what the pH level of your water is and how the chemical additives will affect that level. Determine whether any gains in production will provide sufficient income to make up for the replacement costs of the damage done to the watering system and other components in the house. Perhaps most importantly, consider upgrading the equipment, keeping biofilm out of the watering lines and managing the drinkers so that the litter remains dry and friable. These actions can make the need for corrosive chemicals unnecessary.

**Myth 4:
Adding chlorine to the water is
all you have to do to keep the
lines clean.**

Although chlorine is very effective at killing certain bacteria, chlorine alone will not keep your water lines clean. Chlorine, in the amounts used in poultry watering systems, is not sufficient to kill all of the bacteria. The surviving bacteria can attach to the pipe walls and begin creating a biofilm - a sticky substrate that protects the bacteria and attracts additional bacteria. This active colony of bacteria can have a serious impact on the health of your birds.

Research shows that bacteria entrenched in a biofilm are much more resilient to chlorine than free-floating bacteria. Once established, biofilm will continue to grow to the point where it can inhibit the drinkers, causing them to leak or preventing the birds from activating them.

Another problem is sediment or particulate matter that often ends up in the drinkers and causes them to leak. A filter ahead of the water line (a 5 - 10 micron cartridge) can prevent this from happening.

The most effective method to combat biofilm and sediment is with a regular

schedule of high-pressure flushes. Hydrogen peroxide-based cleaners offer a highly effective tool for eliminating biofilm. Properly formulated, hydrogen peroxide becomes a powerful oxidising agent that scrubs the interior of the pipe and drinker clean of biofilm.

**Myth 5:
An enclosed nipple-type system
cannot work in a sloped house
because the slope increases
pressure at the end of the line,
resulting in more spillage.**

Nipple-type enclosed watering systems work best in poultry houses with perfectly level floors. If the watering line parallels the floor, the result is consistent water pressure throughout the house. Consistent pressure allows each drinker to discharge the same amount of water and makes it easier for the producer to manage the watering system and prevent wet litter. We recommend installing slope neutralisers or pressure reducers at the proper locations on the watering line to solve the problem inherent in sloped houses. These devices help to maintain a tolerable and desired range of low-pressure water in the entire system, allowing the birds to drink without spraying the litter with water. ■